

**Installation Instructions for the Gen 2 Can Am Outlanders  
with the STANDARD SHOCKS**

**Kit comes with 4 CNC Machined 6061 T6 Billet Aluminum spacers as  
pictured below,**



**-Lift the front or rear of the ATV and remove the shocks from the  
machine.**

**-Clean any mud or debris from the shocks**

**-Using some sort of spring compressor (MOST automotive supply stores  
will loan out tools for this free of charge) compress the spring and remove  
the 2 thin factory retaining washers from the top end of the shock.**



**-Or use this method, use 3 straps to make it easier when releasing them.**



**-Remove the spring from the shock and place the spacer on the shock so that it sits against the factory adjustment collar**

**-Put spring back onto shock and re-install the 2 factory spring retaining washers**

**-Carefully release the spring compressor.**

**-Re-Install the shock on the machine**

**-Now repeat on the remaining 3 shocks and you are finished**

**-Shock with spacer installed,**

