

Installation Instructions for the Can Am 1000 Outlander

Kit comes with 4 CNC Machined 6061 T6 Billet Aluminum spacers as pictured below,



- Lift the front or rear of the ATV and remove the shocks from the machine.
- Clean any mud or debris from the shocks
- Using some sort of spring compressor (MOST automotive supply stores will loan out tools for this free of charge) compress the spring and remove the 2 thin factory retaining washers from the top end of the shock.



-Replace those 2 factory retaining washers with one of the spring spacers and slowly and carefully release the spring compressor.

-Re-Install the shock on the machine

-Now repeat on the remaining 3 shocks and you are finished

Front shock with spacer installed,



Rear shock with spacer installed,

