

Front and Rear RZR S Lift Kit



Note: The kit in these pictures has been painted red for easier to see installation pictures. This machine is also set up with the 2 Brothers Triple Exhaust.

RZR S Front Lift Kit Installation

- Jack up the front of the machine
- Remove both upper shock mounting bolts and pull the shocks outward out of the way



-Bolt the front lift kit brackets in place using the supplied 2-1/2" long bolts making sure to place the aluminum spacers into the shock stock mounting location. DO NOT TIGHTEN THESE 2 BOLTS YET



-Bolt the shocks into their now mounting location



RZR S Rear Lift Kit Installation

- Jack up rear of machine**
- Remove both upper shock mounting bolts and pull the shocks outward out of the way the same as you did for the front**
- Bolt rear lift kit brackets in place as pictured. You will not have to remove any parts of the machine, both brackets will fit into place with very little maneuvering. Make sure the aluminum spacers are placed into the stock shock mounting location and that the bracket with the small cutouts are on the side towards the front of the machine to clear the**

exhaust hanger.



-Bolt the shock into its new location

