

Rubberdown Customs Inc. HEAVY DUTY Renegade Rear Fender Supports

If your machine is the XMR model, it will have the factory supports that are known to break very easily. Your XMR will have the hardware required already for mounting these and you will not need a rubber bumper on your supports as there is a factory rubber bushing and factory bolt to connect the fender to the support. The set of supports you get will look like this.



If you don't have the XMR model, your machine did not come with factory supports so your set will include mounting hardware and an installed rubber bumper like this.



Pictured below is the XMR model machine showing no rubber bumper and the factory hardware used to bolt them in place. If you don't have the XMR model machine, it is exactly the same using our supplied frame mounting bolts. Loosely bolt the supports in place and slide them upwards until the rubber stopper is firm against the underside of the fender, then tighten the 2 mounting bolts.

