

Yamaha Kodiak IRS Front Lift kit.

-Jack up ATV and remove both front tires and both upper shock mounting bolts and pull the top end of the shocks outwards out of the way.



-Slide the long thin bracket through the frame channel and put one of the 3/8" bolts in place pointing towards the rear of the machine. It is a VERY tricky tight fit but these bolts WILL go in.



-Place one of the 2 small brackets on the end of the bolt and put a nut on to keep it in place, DO NOT TIGHTEN ANY BOLTS UNTIL ALL BOLTS ARE IN PLACE.



-Once you have this completed on both sides, you can put the upper end of the shock into its new location, THIS TIME, put the bolt in pointing the opposite direction, AGAIN, IT IS A VERY TIGHT AND TRICKY FIT BUT THE BOLTS WILL GO IN.



Rear Lift

-Jack up ATV and remove both upper shock mounting bolts and pull the top end of the shocks outwards out of the way.

-Bolt the rear lift brackets in place as pictured below with the 3/8" bolts provided with the kit. Make sure you insert the aluminum bushings into the original shock mounting locations BUT leave all the bolts loose for right now.



-Now bolt the shocks into their new location and tighten all 4 bolts.



